


CONTROL STICK ASSEMBLY CS-8 WITH RELAYS WIRING DIAGRAM



- Right Pushbutton - BROWN
- Common for the 2 Pushbuttons - WHITE
- Left Pushbutton - PINK
- Ground - GREEN
- Together they activate the Aileron Servo
 - BLUE
 - VIOLET
- YELLOW - Trigger Button
- WHITE - Common for the 2 Buttons
- GRAY - Index Button
- RED - Positive (goes to the 1A Breaker)
- ORANGE
- BLACK
 - Together they activate the Elevator Servo

Caution: Do not short the Servo wires with the Breaker ON.